

Weekly and monthly maintenance on davits

Year	Crane serial No.	Ship	IMO No.

Maintenance of davits			
Working task on the winch	Weekly	Every second month	Half yearly
Lowering and hosting of the winch with empty hook.	X		
Check oil level on the oil level glass on the winch.	X		
Check the winch for leakage.	X		
Oil change on the winch.			X
Working task on the slewing	Weekly	Every second month	Half yearly
The jib is turned in and out with the slewing gear.	X		
Slewing ring or kingpost must be greased while turning the jib.		X	
Greasing of worm wheel and shaft if applicable.		X	
The pinion shaft coming out from the slewing gear must be greased if applicable.	X		
Check oil on the slewing gear if applicable.	X		
Change oil on the slewing gear if applicable.			X
Drain plug in foundation bottom is screwed out for draining of condense water if applicable.		X	
Bottom drain holes beneath slewing ring mounting on the foundation are visually inspected for passage if applicable.		X	
Working task on the hoisting wire and loose gear	Weekly	Every second month	Half yearly
The hoisting wire must be visually examined for wear and tear.			X
Loose gear should be visually examined for wear and tear.			X
Hooks must be examined for function.	X		
Maintenance of hooks. See hook supplier's instructions.	*****	*****	*****

Note: Annual and 5 year inspection must be performed by authorised personal only

Weekly and monthly maintenance on davits

Year	Crane serial No.	Ship	IMO No.

Working task on the block and rope pulleys	Weekly	Every second month	Half yearly
The blocks and rope pulleys must be greased.		X	
Additional working task on MOB boat davits	Weekly	Monthly	Half year
The MOB boat is turned or luffed with the hyd. manoeuvring valve.	X		
The MOB boat is turned or luffed out on stored power			
It is checked that the hyd. pump recharges the accumulators after the jib has been turned or luffed out. Plug from remote control has to be taken out to activate this function.	X		
The empty hook is hoisted by the E-motor.	X		
The electric hoisting limit stop is tested.	X		

Note: Annual and 5 year inspection must be performed by authorised personal only

Weekly and monthly maintenance on davits

Year	Crane serial No.	Ship	IMO No.

Monthly check has been done												
	Jan	Feb	March	April	May	June	July	Aug	Sep	Oct	Nov	Dec
Sign												
Weekly check has been done												
	1	2	3	4	5	6	7	8	9	10	11	12
Sign												
Weekly check has been done												
	13	14	15	16	17	18	19	20	21	22	23	24
Sign												
Weekly check has been done												
	25	26	27	28	29	30	31	32	33	34	35	36
Sign												
Weekly check has been done												
	37	38	39	40	41	42	43	44	45	46	47	48
Sign												
Weekly check has been done												
	49	50	51	52								
Sign												

Note: Annual and 5 year inspection must be performed by authorised personal only